

ToolTonic, J-B. Tschäppät
Montagne-de-Cernier 7
CH-2052 La Vue-des-Alpes
Tél +41 (0)32 853 12 00
Fax +41 (0)32 853 12 11
info@tooltonic.com
www.tooltonic.com

ASYMMETRIC SHARPENING FOR HARD SNOW AND SOFT SNOW ON THE SAME PAIR OF SKIS

You can adapt your ski pair to the snow conditions by making a differentiated sharpening of the left edge and the right edge of each ski. So you can reverse the left / right ski boot to obtain:

- either very sharpened skis for hard snow (* with or without the use of the Ice-Catcher over-sharpener)
- or skis with very good behavior for soft snow thanks to a tip which remains more on the surface of the snow during the turn (see figures below).

To distinguish the two variants, it is enough to affix the attached stickers on the skis.

Arrows «H» against the inside for hard snow «Hard snow»

- **BLUE LINE** very sharp sharpening along the length of the ski, including the tip.
- **RED LINE** over-sharpening of the central part of the ski with the Ice-Catcher.

Arrows «S» against the inside for soft snow «Soft snow»

- **BLUE LINE** the edge is sharp but not at the zone of the tip.
- **GREEN LINE** the tip and the first 15 centimeters in contact with the snow are rounded; the tip remains more on the surface of the soft snow and the ski is better guided.

* We also recommend asymmetrical sharpening without necessarily over-sharpening.

